Table of Contents

Safety 1

Electrical safety 1

Installation safety 1

Cleaning safety 1

Special notes on LCD monitors 2

Package contents 2

Installation instructions 3

Placement 3

Installation 3

External controls 4

Image adjustment 5

Screen adjustment 7

Attachments 8

Plug and play 8

Power saver 8

Troubleshooting 8

Technical specifications 9

Display modes 10

Downloaded from www.Manualslib.com manuals search engine

Safety

Electrical safety

Note: To ensure your safety and prolong the life of the product, read the following safety recommendations carefully before using the product for the first time.

- Do not touch the inside of the monitor. Only authorized and qualified technicians should open the LCD monitor case.
- Hold the plug (not the power cable) when you connect the plug to the socket. Make sure your hands are dry.
- This product should only be operated with the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- This product is equipped with a 3-prong plug, (a plug having a third grounding pin). This plug will only fit into a grounded power outlet. If you are unable to insert the grounded plug into the outlet, contact your electrician to replace your obsolete outlet. Do not use a two-prong adapter instead of the grounded plug.
- Don’t expose your LCD monitor to water, or any environment with a high temperature or humidity, such as kitchens or swimming pools. Flower vases filled with water are also dangerous.
- If your LCD monitor operates abnormally (i.e., releases smoke, noise or a smell), remove the plug immediately and contact your authorized dealer or service center.

Installation safety

- Don't touch your LCD monitor with your fingers or any hard object. Avoid scratching or leaving any oil sludge on the surface of the display.
- Protect your LCD monitor by installing it in a place that is well-ventilated, moisture proof, and dust-free.
- Don’t install your LCD monitor near a heat source, (i.e., ovens, space heaters, fire places, furnaces or in the sun).
- To avoid electric shock, or dropping, install your LCD monitor in a place where children will not touch it. Secure your LCD monitor firmly and explain the safety rules to children, if required.
- When installing your LCD monitor or adjusting its angle, attention should be paid to the loading capability and leveling of the structure supporting the LCD monitor.

Cleaning safety

- Don’t spray cleanser or water onto your LCD monitor or its case.
- When cleaning your LCD monitor, make sure that no liquid permeates into the inside of the LCD monitor or any accessory.
- Moisten a clean, soft, lint-free cloth with water or glass cleaner without alcohol. Squeeze it so it's just a little damp and wipe the surface of your LCD monitor gently. It is recommended to use a silk cloth that is exclusively used to clean the display.

Downloaded from www.Manualslib.com manuals search engine

Special notes on LCD monitors

The following symptoms are normal for LCD monitors and do not indicate a problem with the device:

- Due to the nature of the fluorescent light, the screen may flicker during initial use. Turn off the power switch and then turn it on again to make the flicker disappear.
- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- The LCD screen has effective pixels of 99.99% or more. It may include blemishes of 0.01% or less (caused by a missing pixel or a pixel that is always lit).
- When the same image is displayed for hours on end, its afterimage may remain after switching to a new image. When this happens, the screen will recover slowly by changing the image. Turning the LCD monitor off for several hours will also correct this problem.

Package contents

LCD display (with speakers)



D-Sub signal cable

DVI signal cable (optional)

Quick Start Guide

Power cable



Audio cable

User's Guide (CD)

Downloaded from www.Manualslib.com manuals search engine

Installation instructions

Placement

Note: Read the Safety section carefully before starting the installation.

When installing your LCD monitor, consider the placement of the monitor:

- To minimize the reflection of the monitor, protect your eyes, and ensure premium quality, don't install your LCD monitor near windows or where there is backlight. Keep the monitor at least 30 cm away from your eyes.
- The upper edge of the monitor should be just a little higher than your line of sight.
- Adjust the front and back dip angles of the monitor, so that you can view the display comfortably.

Installation

Connecting the base to the monitor

Take the base out of the box and place it on a flat table.

- Position the monitor on top of the base.
- Connect the base into the neck of the monitor along the track.
- You will hear a click sound when the base and the monitor are properly connected.



Connecting the LCD monitor to a PC

- Make sure that the power supply of your PC is turned off and the power plug is removed.
- Connect and fasten both ends of the signal cable to your PC host and LCD monitor, respectively.
- If your LCD monitor has built-in speakers, connect the audio cable attached to the monitor from the sound card output of your PC to the audio input on the back of your LCD monitor.
- Connect the attached power cable to your LCD monitor.
- Plug the power cable into the receptacle.
- Use the cable tie to bind up the power cord and the D-sub signal cable / DVI-D cable.
- Turn on the power supplies of your PC and LCD monitor.



❶ Power cable
❷ Audio cable
❸ DVI signal cable (optional)
❹ D-Sub signal cable

Downloaded from www.Manualslib.com manuals search engine

External controls



1	⏻	Power source	Power On/Off Green indication: Power is on and normal. Orange indication: Sleep status in the energy-saving mode. Colorless indication: Power off.
2	Menu	OSD Menu	Press this button to enter OSD. Press it again to exit OSD.
3	>	Plus	Press this button for selection or adjustment when OSD is started.
4	<	Minus	Press this button and click < and > to adjust volume when OSD is not started (for the model with speakers only).
5	Auto	Automatic adjustment	Press this button to exit the manual when OSD is started. Press this button for the display to optimize the position, phase and clock pulse automatically when OSD is not started.
6	Speaker	(For models with speakers)	

Downloaded from www.Manualslib.com manuals search engine

Image adjustment for analog

The image settings of your LCD monitor were adjusted to their optimal status for analog TV before shipment. (See Page 9). If you want to adjust the image settings to suit your personal preference, follow the steps below:

1. Click Menu to display the OSD window as shown in the following figure.
2. Click Plus or Minus to select the function to be adjusted as shown in the following figure.
3. Click the Menu again to select the function to be adjusted.
4. Click Plus or Minus to change current settings.
5. To exit the OSD window, select "EXIT" to close and save changes. To change other settings, repeat steps 2-4.



(Analog)

Downloaded from www.Manualslib.com manuals search engine

Image adjustment for digital

The image settings of your LCD monitor were adjusted to their optimal status for digital TV before shipment. (See Page 9). If you want to adjust the image settings to suit your personal preference, follow the steps below:

1. Click Menu to display the OSD window as shown in the following figure.
2. Click Plus or Minus to select the function to be adjusted as shown in the following figure.
3. Click the Menu again to select the function to be adjusted.
4. Click Plus or Minus to change current settings.
5. To exit the OSD window, select "EXIT" to close and save changes. To change other settings, repeat steps 2-4.



(Digital)

Downloaded from www.Manualslib.com manuals search engine

Screen adjustment

Function Definition

Primary directory symbol	Secondary directory symbol	Secondary directory items	Description
		Contrast	Adjusts the contrast between the foreground and background of an image on the screen.
		Brightness	Adjusts the background brightness of the screen.
		Phase	Adjusts the focus of the image (for analog input adjustment only).
		Clock pulse	Adjusts the clock pulse of the image (for analog input adjustments only).
		Horizontal	Moves the image left and right on the screen (for analog input adjustments only).
		Vertical	Moves the image up and down on the screen (for analog input adjustments only).
	N/A	Warm color temperature	Sets the color temperature to warm white.
	N/A	Cold color temperature	Sets the color temp to cold white.
		User Definition/Red	Adjusts red/green/blue gain.
		User Definition/Green	
		User Definition/Blue	
	N/A	**English**	Used to select the language you want.
	N/A	**繁體中文**	
	N/A	**Deutsch**	
	N/A	**Français**	
	N/A	**Español**	
	N/A	**Italiano**	
	N/A	**简体中文**	
	N/A	**日本語**	
	N/A	**Hollands**	
	N/A	**Suomalainen**	
	N/A	**Русский**	
		Horizontal	Moves OSD left and right.
		Vertical	Moves OSD up and down.
		OSD time display	Adjusts OSD time display settings.
	N/A	Auto adjustment	Sets up horizontal, vertical, sequence and focus automatically (for analog input only).
	N/A	Analog digital	Used to select the input source you want (for DVI input only).
	N/A	Message	Display resolution, H/V frequency and the input port used for current input timing function.
	N/A	Restore	Restores system to default settings.
	N/A	Exit	Closes the OSD window and saves changes.

Downloaded from www.Manualslib.com manuals search engine

Attachments

Plug and play

- The product provides the latest VESA ***plug and play*** feature to prevent complicated and time-consuming installation procedures. The ***plug and play*** feature allows your computer system to identify the LCD monitor easily and set up its functions automatically.
- The LCD monitor transfers the ***Extended Display Identification Data*** (EDID) to your computer system via the ***Display Data Channel*** (DDC), so that your computer can use the self-setting function of the LCD monitor.

Power saver

- The LCD monitor has a built-in Power Control System (Power Saver).
- When the LCD monitor is not operated for a period of time, the Power Control System automatically sets the system at low voltage status to save power. Move the mouse slightly or press any key to return to normal operation.
- The Power Saver function can only be operated by the display card of the computer system. You can set up this function from your computer.
- The LCD monitor is compatible with EPAENERGY STAR NÜTEK when used with VESA DPMS.
- To save power and extend the life of the product, turn off the LCD monitor power supply when it is idle for a long time or not being used.

Troubleshooting

Power LED does not light	• Check that the power switch is turned on. • Make sure the power cable is connected.
Icon off	• Check that the power switch is turned on. • Make sure the power cable is connected. • Ensure that the signal cable is inserted in the receptacle appropriately. • The Power Saver may turn off the monitor automatically during the operation. Make sure the monitor is restored when you press any key from the keyboard.
Color default	• Refer to "Color Temp. Adjustment" to adjust RGB color or select color temperatures.
Instability or ripple	• Remove any electronic equipment in the vicinity that may cause EMI interference. • Check the signal cable of the monitor to ensure that none of the pins are bent.
Image offset or wrong size	• Press the auto adjustment button to automatically optimize the screen. • Set up the reference position.

Downloaded from www.Manualslib.com manuals search engine

Technical specifications

LCD panel (backlight source)	Panel dimension	Diagonal 510.3 mm (20.1 inch) LCD monitor
	Max. resolution	1,400 x 1,050 / SXGA
	Max. pixel	Up to 16.2 M true color
	Pixel span	Horizontal 0.291mm x Vertical 0.291mm
	Brightness	300 cd/m^2
	Contrast	600 : 1
	LC response time	8 ms
	Visual angle	Horizontal 150° / Vertical 130°
	Effective display	Horizontal 408.24 mm x Vertical 306.18 mm
Input signal	Signal mode	Simulated video frequency: 0.7 Vpp, 75Ω (separate SYNC and composite SYNC)
	SYNC frequency	Horizontal 30 kHz – 82 kHz x Vertical 56 Hz – 76 Hz
	Max. pixel clock	140MHz
Input terminal	Image	D-Sub 15 PIN (VESA) / DVI-D (Optional)
	Audio	Phone Jack, d=3.5 mm (Optional)
Power transformer		AC100 – 240 Volts, 50 – 60 Hz
Power consumption		55 W / Standby 1W / Power-Off 1W
Environmental conditions	Temperature	5°C – 35°C (operation) / -20°C – 55°C (storage)
	Humidity	20% – 80% (operation) / 20% – 85% (storage)
Actual dimensions (W x D x H)		538 x 158 x 470 mm
Net weight		5.3 kg
Safety standard		TCO03;UL/CUL;TÜV-GS;CE/LVD;TÜV-ERGO;CB;CCC;FCC-B;VCCI-B; CE/EMC;C-Tick; BSMI; ISO 13406-2;EPA;PCT;NOM;WEEE;PSB;HG

Lamp disposal

Lamp(s) inside this product contain mercury and must be recycled or disposed of according to local, state or federal laws. For more information, contact the Electronic Industries Alliance at www.eiae.org. For lamp-specific disposal information, check www.lamprecycle.org.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus meets all requirements of the Canadian Interference- Causing Equipment Regulations.
Cet appareil numérique de la class B respecte toures les exigencies du Réglement sur le materiel brouilieur du Canada.

Downloaded from www.Manualslib.com manuals search engine

Display modes If the signal of your PC system is the same as one of the following reference signal modes, the screen will be adjusted automatically. If not, the screen will not display or only the LED lights will display. For more information about the adjustment mode, refer to the instructions of your display card.

Display Mode		Hor. Frequency (kHz)	Vert. Frequency (Hz)	Pixel Frequency (MHz)	SYNC Polarity (H/V)
VESA	VGA 640x480	31.469	59.940	25.175	-/-
		37.861	72.809	31.500	-/-
		37.500	75.000	31.500	-/-
	SVGA 800x600	35.156	56.250	36.000	+/+
		37.879	60.317	40.000	+/+
		48.077	72.188	50.000	+/+
		46.875	75.000	49.500	+/+
	XGA 1024x768	48.363	60.004	65.000	-/-
		56.476	70.069	75.000	-/-
		60.023	75.029	78.750	+/+
	SXGA 1152x864	67.500	75.000	108.000	+/+
	SXGA 1280x1024	63.981	60.020	108.000	+/+
		79.976	75.025	135.000	+/+
	SXGA+ 1400x1050	65.317	59.978	121.75	-/+
VGA TEXT	720 x 400	31.469	70.087	28.322	-/+
Macintosh	640x480	35.000	66.667	30.240	-/-
	832 x 624	49.725	74.500	57.283	-/-
	1024 x 768	60.150	74.720	80.000	-/-

Downloaded from www.Manualslib.com manuals search engine